


# IMPORTANT INFORMATION!

## How to mount antennas outdoors.

Best antenna position is as high as possible with a good all-round view to get a high range for your receiver.


To **discharge static electricity** from the system, mount the antenna:

- on a metal mast with **electrical grounding**.
- on a balcony rail or drip rail with conductive connection.
- with a wire to a balcony rail or drip rail.



### No Tape!

Don't tape the antenna socket when the N-type connector is inside a tube. This case is standard for Jetvision antennas, because the tube protects the antenna socket from weather impacts like rain. The tape can lead to a cavity where water collects and affects the function of the antenna.



### Attention:

Outdoor antennas must be earthed, because static charges or overvoltages (lightning strike) can destroy your equipment and thereby endanger your life.



Jetvision assumes no liability for unearthed antennas and any defects caused by such!